


ACT LABS PERFORMANCE PEDALS



Disassembly Guide




Step 1 - Remove the 11 screws from the base.



Step 2 - Remove the bracket screws
and then lift the brackets from the
pedal cylinder.

Step 3 - Peel off the hot glue, then lift the pedal from the base and remove the potentiometer.





DO NOT cut the potentiometer wires unless you are replacing it.

Step 4 - With a small screwdriver remove brass retaining pin. The springs will separate from the assembly.